





FRONT
Room side



BACK
Inside the wall



EDGE
Seen from below, at twice the scale of the front and back



BACK, 3D VIEW

NOTES

1. Cut the wall opening 6 to 8 in on each side. Do not cut it to the cover size.
2. The rim rests on the wall; the fixed tabs and the sliding tab hold the panel from behind the drywall.
3. Sliding tab shown at rest. The wire spring is not shown.
4. Dimensions in inches [millimetres]. Views are not to scale.
5. Drawn by Buy Access Panels from the manufacturer's CAD. Not a manufacturer-certified drawing or a cutout template. Follow the instructions supplied with your panel.

Easy-Exs SAP0808

8x8 in Spring-Loaded Plastic Drywall Access Panel

SOLD AS 8 × 8 in	**COVER** 10 × 10 in
CUT OPENING 6 to 8 in each side	**UNITS** in [mm]
SOURCE Manufacturer's CAD	**DRAWN** 2026-11-12

buyaccesspanels.com

Not to scale